

# Download Kindle Instructions Manual

Kindle User's Guide 6 Chapter 1 Getting Started When you're reading a book, menu items specific to that task include Change Font Size, Go To..., Sync to Furthest Page Read, Book Description, Search This Book, Add Bookmark, View Kindle User's Guide, 2nd Edition Chapter 1 Getting Started 7 Mac OS X: Click the Eject button next to the Kindle in any Finder window, or drag it from the Desktop to the Trash. Your Kindle will then exit USB drive mode, but will continue to charge.